

Fast Operation Guide of SEMS Portal


Version : 1.2

(Web : <https://www.semsportal.com> ; APP : SEMS Portal)

No	Version No.	Modification Content	Date	Remarks
1	1.0	-	2018-08-27	First release
2	1.1	Add Detailed description of permission	2018-09-30	
3	1.2	Make some corrections	2018-10-18	

Detailed description of permission:

User type	User role	Create sub-level organization	Delete sub-level organization	Create account for colleague	Delete account of colleague	View plant	Create plant	Edit plant	Delete plant
Organization account	Administrator	Yes	No	Yes	Yes	Yes, See note 2#	Yes	Yes, See note 3#	Yes, See note 4#
	Technician	No	No	No	No	Yes, See note 2#	Yes	Yes, See note 3#	Yes, See note 4#
	Browser	No	No	No	No	Yes See note 2#	No	No	No
End user	Owner of plant	No	No	No	No	Yes	Yes	Yes	Yes, See note 5#
	Visitor of plant	No	No	No	No	Yes	Yes	No	No, See note 5#



- Note 1#:**
1. First-level organization is created by GOODWE, please contact the GOODWE sales or service.
- Note 2#:**
2. User C1/C2/C3 can view 31# & 32# plants;
3. User B1/B2/B3 can view 21# & 22# plants and 31# & 32# plants;
4. User A1/A2/A3 can view 11# & 12# plants and 21# & 22# plants and 31# & 32# plants.
- Note 3#:**
5. User C1/C2/C3 can edit 31# & 32# plants;
6. User B1/B2/B3 can edit 21# & 22# plants;
7. User A1/A2/A3 can edit 11# & 12# plants.
- Note 4#:**
8. User A1/A2/A3 deleting one plant in 12# plants, the plant will be eliminated from SEMS portal;
9. User A1/A2/A3 deleting one plant in 11# plants, user A1/A2/A3 cannot view the plant longer, but the plant is still available for the owner;
10. Same rules for user B1/B2/B3 and user C1/C2/C3.
- Note 5#:**
11. Owner deleting plant in 11# plants, the plant will be eliminated from SEMS portal;
12. Owner deleting plant in 12# plants, the owner cannot view the plant longer, but the plant is still available for the user A1/A2/A3;
13. Visitor deleting plant in 11# & 12# plants, the visitor cannot view the plant longer, but the plant is still available for the owner and user A1/A2/A3.


1. How to Register A Distributor Account

You can get one from your inverter supplier. If you cannot get one from the supplier, you can try to contact GoodWe after-sale service by service@goodwe.com

2. How to Create A New Plant

Click **【Settings】** → **【Plant Setup】**

You can see the page as below.



Click **【Create】** → **【Add】** in 'Owner' and 'Visitor' column → Enter information of the plant → click **【Submit】** at the bottom. Then you get a new plant.

- **Notes:**

1. Before you add a visitor, add the owner first. By the way, one plant can ONLY have one owner, but can have several visitors.
2. Enter an email address to add an owner or a visitor.
3. Click the plant name in the plant list, you can edit the information of the plant. The modification is accepted once you click the blank area on the page.



● **Notes:**

- 1) Best performance is available under resolution 1920*1080;
- 2) Press 'F11' (Fn+F11 for laptop) and you can get full screen view. Press 'F11' again to exit full screen.
- 3) Click the button at lower-left side, you can switch to other pages.
- 4) Settings for main dashboard
Click **【Settings】** -> **【System Setting】** , you can get the page below.

Basic Setting:

Default map of Main dashboard (Drag and zoom the map below to set): [shanghai](#)



Main Dashboard Carousel Form: A nine-square grid Lists

Main Dashboard Carousel Range: Generating Plants All plants

Main Dashboard Carousel Speed: Sec

Main Dashboard Module Parameter Setting:

Constructing&Planning: Connected Plants, Capacity MW
 Automatic system calculation

Constructing: Plants, Capacity MW

Planning: Plants, Capacity MW

Coefficient of Environmental Contribution: 1 kWh = kg CO2 Reduction
 1 kWh = Planted Trees
 1 kWh = kg Coal Savings

Main dashboard Module Customization:



Default profit ratio for new created plant:

Profit Ratio: EUR/kWh

Advanced Settings:

Main Dashboard Logo: Please upload a picture with at least a size of 430*48

System Logo: Please upload a picture with at least a size of 210*48


 **GOODWE**

保密资料

产品介绍 © GOODWE

5. How to Get Historical Data

Click **【Reports】** → **【Data Selection】** , you can get:




Click **【Generate Data】** after you choose the plant , the device SN and the index.

- **Notes:**

1. In the curve mode, the maximum measurement units of the indicators you can choose is 2 units.

6. How to Get Generation Reports

Click **【Reports】** → **【Monthly Report】** or **【Annual Report】** or **【User-defined Report】**




● **Notes:**

1. You can generate reports based on the plants, locations and organizations.


7. How to Set Generation Email

Click **【Settings】** → **【Push Setting】** → Enable **【Receive Push Mail of Generation Info】** → Choose in **【Push Frequency】** → **【Plants Range】** to select the plant that you are monitoring.



8. How to Manage Your Account System (for Administrator account of Company user)

Click **【Settings】** → **【Organization Structure】** , you can get the page below:




8.1 Create sub-level distributor account

Click icon  → Fill in information in right side → **【Submit】**

- **Notes:**

1. Please ensure that the representative's full name of the sub-level distributor is **COMPLETELY** correct because it will be used for authentication.
2. An email will be sent automatically to the email address you filled in

8.2 Create more accounts for your company



Click **【Account Info】** → **【Add】** → Fill in the email address → Select account role → **【Submit】**

● **Notes:**

1. There are 3 types of account role as administrator, technician and browser. You can check the differences on the page of **【Role Permissions】** .
2. If your colleague registered account on the website or APP as a distributor user, you can accept his application and choose a proper role for him.